

Components

4R220 DVS Pump – Scope of Delivery



- ① Spacer plate
- ② Screws
- ③ Distance bushings
- ④ Valve with dummy
- ⑤ Lamination adapter
- ⑥ Fixation ring
- ⑦ Piston
- ⑧ Plaster screw
- ⑨ Dummies
- ⑩ Wrench

Components

4R220=1 Non weight-bearing version



Allows for offset of adapter plate in fabrication.

Does not have a 4-hole distal connection.

Additional adapter required

Pump must still be placed directly in line with socket to allow proper liner connection.

Components

Spare parts



4X320 Piston



4X339 Fixation ring



4X322 Valve for lamination adapter



4X326 Dummy Set



4X338 Wrench



4X314 Spacer plate